

Operation of PrimeTime DMX Controls 2019

The 3-button control panel on the back of your PrimeTime LED luminaire is easy to use. With it, you can set your DMX address or switch the light to “manual” and adjust brightness –

- When your light is powered-up you will see the PrimeTime logo in the display window
- You will see a green indicator light when it detects a DMX connection



- Press the “M” button and you will see a menu of “DMX” and “manual”
- Use the “up” and “down” buttons to indicate the mode you want, then press “M” to select it



- If you select “DMX” you will see a number displayed. That will be the current DMX address set for this light
- To change the address, use the up and down buttons to indicate the address number you desire (from 1 to 512)
- When you see the number you want, press the “M” button again and you will see a message indicating the DMX address is saved



- NOTE: Once the address is saved, your PrimeTime light will automatically default to that address every time it's powered up. If you switch to manual for a time and come back to DMX, it will still default to the saved address
- If you select "manual" from the main menu, you will see a percentage displayed. That will be the current manual brightness level setting for this light
- To change the manual brightness, use the "up" and "down" arrows to select the level you desire
- Press the "M" button again and you will see a message indicating the brightness level is saved



- NOTE: Once you set a manual brightness level, your PrimeTime light will default to that level every time it's powered up. If you switch to DMX, and come back to manual, it will still be at the saved level

Anytime your PrimeTime DMX control panel is idle for 5 minutes, it will automatically go to sleep. To activate it, press any button and you will again see the PrimeTime logo, then you can proceed as described above.

 **PrimeTime**
LIGHTING SYSTEMS®
4124 Billy Mitchell Drive
Addison, TX 75001
214-393-5998
PrimeTimeLighting.com